

[USAF] SHL-2083 (DTA)



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 11:

BELGRANO 5A (GBE5A): Turn right to intercept EZE R-126 to intercept 10 DME arc to EZE13. Turn left to intercept and continue on EZE R-182 to GBE VOR.

KUKEN 5A: Turn right to intercept EZE R-126 to EZE12 (EZE 4 DME), then intercept PTA R-290 (hdg 110°) to EZE16. Turn left to intercept and continue on BOS R-076 to EZE17, then via approved transition.

LA PLATA 5B (PTA5B): Turn right to intercept EZE R-126 to EZE12 (EZE 4 DME), then intercept PTA R-290 (hdg 110°) to PTA VOR. Then via approved transition.

TAKE-OFF RWY 17:

BELGRANO 5A (GBE5A): Turn right to intercept EZE R-182 to GBE VOR.

KUKEN 5A: Turn right to intercept EZE R-182 to EZE13 (EZE 10 DME). Turn left to intercept and continue to BOS R-076 to EZE17, then via approved transition.

LA PLATA 5A (PTA 5A): Turn right to intercept EZE R-182 to EZE13, turn left to PTA R-272 (hdg 092°) to PTA VOR then via approved transition.

TAKE-OFF RWY 29:

BELGRANO 5A (GBE5A): Climb on rwy hdg to EZE11 then turn left hdg 275° and follow the 10 DME arc to EZE13. Turn right to intercept EZE R-182 to GBE VOR.

KUKEN 5A: Climb on rwy hdg to EZE11, then turn left to hdg 275° and follow the 10 DME arc to EZE13, Turn left to intercept BOS R-076 to EZE17, then via approved transition.

LA PLATA 5A (PTA5A): Climb on rwy hdg to EZE11, then turn left to hdg 275° and follow the 10 DME arc to EZE13. Turn left to PTA R-272 (hdg 092°) to PTA VOR, then via approved transition.

TAKE-OFF RWY 35:

BELGRANO 5A (GBE5A): Climb on rwy hdg to EZE10 then turn left to hdg 275° to intercept the 10 DME arc to EZE13. Then turn right to intercept GBE R-182 to GBE VOR.

KUKEN 5A: Climb on rwy hdg to EZE10 then turn left to hdg 275° to intercept the 10 DME arc to EZE 13. Then turn left to intercept PT R-076 to EZE17 then via approved transition.

LA PLATA 5A (PTA5A): Climb on rwy hdg to EZE10 then turn left to hdg 275° and follow the 10 DME arc top EZE13. Turn LEFT to intercept PTA R-272 (hdg 092°) to PTA VOR. Then via approved transition.

TRANSITIONS

DORVO: Continue on PTA R-076 to DORVO intersection.

ESLAN: Intercept PTA R-097 to ESLAN intersection.

KOVUK: Intercept PTA R-132 to KOVUK intersection.

KUKIN: Intercept PTA R-347 to KUKEN.

PAPIX: Intercept PTA R-347 to EZE18, turn right to intercept EZE R-066 to PAPIX.

TEDAR: Intercept PTA R-169 to TEDAR intersection.